


THOR H Series Laser Pointer Manual



- ① Install star cap to project patterns, and screw in/out to adjust the focus.
- ② On/Off button.
- ③ Mind the battery type and direction.
 - Green laser and Blue laser: 2x16340 batteries. Positive side face to the button.
 - Red laser and Violet laser: 2x16340 batteries. Positive side face to the spring.

Technical Specs

Name	THOR H Series Laser Pointer		
Size	21*3*3 cm		
Laser Class	Class 4		
Laser Type	Direct Diode		
Wavelength	450nm blue	520nm green	650nm red
Output Power	1600mw / 3000mw	100mw	100mw
Beam Divergence	3.6mRad	2.4mRad	1.2mRad
Beam Diameter At Aperture	4mm At Aperture <20mm at 10 meters	4mm At Aperture <20mm at 10 meters	4mm At Aperture <8mm at 10 meters
Laser Body	Aircraft-Grade Aluminum		
Laser Finish	Black		
Modes	Single On/Off Continuous Mode		
Power Supply	2*16340 3.7V Lithium-Ion Rechargeable Battery		
Weight	0.3kg		

Important things:

1. Must use safety goggles. Get one from us if you don't have one.
2. Don't light up over 2 minutes each time, totally cool down before you use it again, if or, it may be damaged by overheated.
3. Keep away from children, don't direct to eyes. User is responsible for any improper using way.