

THOR ULTRA Laser Pointer Manual



- ① Install star cap to project patterns, and screw in/out to adjust the focus.
- ② From left to right: Power LED, Mode button, On/Off button.
- ③ Battery button with key lock.
- ④ Charger hole.
- ⑤ This laser uses 2x26650 batteries

Technical Specs

Name	Thor Ultra	
Size	35.5*4*4 cm	
Laser Class	Class 4	
Laser Type	Direct Diode	
Wavelength	450nm blue	520nm green
Output Power	3000mw / 5000mw	1000mw
Beam Divergence	3.6mRad	3.6mRad
Beam Diameter At Aperture	4mm At Aperture <20mm at 10 meters	4mm At Aperture <20mm at 10 meters
Laser Body	Aircraft-Grade Aluminum	
Laser Finish	Black	
Modes	Multiple Modes: weak, strong, sos	
Power Supply	2*ICR26650 3.7V Lithium-Ion Rechargeable Battery	
Weight	0.5kg	

Important things:

1. Must use safety goggles.
2. Don't light up over 2 minutes each time, totally cool down before you use it again, if or, it may be damaged by overheated.
3. Keep away from children, don't direct to eyes. User is responsible for any improper using way.