


# Thor H 2 Manual



- ① **Screw in/out to adjust the laser beam.**
- ② **On/Off button.**
  - **Press 1 time is the weak light mode.**
  - **Quick press 2 times is the strong light mode.**
  - **5 seconds press is the SOS mode.**
- ③ **This laser uses 2 x 26650 Li-ion 3.7V batteries.**
- ④ **Safety switch keep you away from misoperation.**

## Technical Specs

Name	Thor H 2
Size	28*3.5*3.5 cm
Laser Class	Class 4
Laser Type	Direct Diode
Wavelength	445nm Blue, 520nm Green
Output Power	1000mw, 1600mw, 3000mw, 5000mw
Laser Body	Aircraft-Grade Aluminum
Laser Finish	Black, Silver
Beam Divergence	3.6 mRad
Beam Diameter	4mm At Aperture, <20mm at 10 meters
Modes	Multiple Mode
Power Supply	2*26650 3.7V Lithium-Ion Rechargeable Battery
Weight	0.28kg

### Important things:

1. Must use safety goggles.
2. Don't light up over 2 minutes each time, totally cool down before you use it again, if or, it may be damaged by overheated.
3. Keep away from children, don't direct to eyes. User is responsible for any improper using way.